

KF32LS200_500_DEMO

EXCON1


EXCON2

EXCON3

- | | | |
|----|------|------|
| 1 | GND | 3.3V |
| 3 | PC11 | PC12 |
| 5 | PC10 | PB15 |
| 7 | PB12 | PB13 |
| 9 | PB3 | PB11 |
| 11 | PB1 | PB2 |
| 13 | PC9 | PB14 |
| 15 | PC7 | PC8 |
| 17 | PC3 | PC4 |
| 19 | PC1 | PC2 |

- | | | |
|----|------|------|
| 1 | GND | 3.3V |
| 3 | PF4 | PF5 |
| 5 | PB10 | PB9 |
| 7 | PB6 | PF7 |
| 9 | PB5 | PB4 |
| 11 | PE6 | PA14 |
| 13 | PA13 | PA12 |
| 15 | PA11 | PA10 |
| 17 | PA9 | PA8 |
| 19 | PA1 | PA0 |

- | | | |
|------|------|----|
| 3.3V | 3.3V | 1 |
| 3.3V | 3.3V | 3 |
| GND | GND | 5 |
| GND | GND | 7 |
| PH12 | PD15 | 9 |
| PD14 | PD13 | 11 |
| PH11 | PH10 | 13 |
| PD10 | PD4 | 15 |
| PD3 | PC14 | 17 |
| PC13 | PG6 | 19 |



BUTTON

R1

Rb
Ra


CF1
C8
C9

X1
C3
C4



U2

R17
R16



C2
F1
D1
R23
R22

C5
R15

R21
R18

POWER
C10
R19

STATUS
C11
R20




USB

RESET

USER

DOWNLOAD



VCC
GND
DTA
CLK